

T661 KLONDIKE™ SUMMARY APPLICATION PROCESS

June 26, 2012
Page 01 of 02

Quick Facts:

For best results, apply over smooth surfaces. If the substrate is drywall, the substrate should be level 4 or level 5. Due to the random nature of KLONDIKE, it has some minor hiding abilities.

There are now two (2) different versions of Klondike. A) **KLONDIKE (traditional)** and B) **KLONDIKE LIGHT**. The mixing instructions are different for the two different bases.

Here are a few additional facts:

- The COLORI (pigments) may be used for either KLONDIKE or KLONDIKE LIGHT (but in different proportions).
- The primer, PRIMER 900 or PRIMER 1000 helps to create the color. Using the wrong primer will result in some other color than the intended color.
- DO NOT stir the COLORI with a drill and paint plaster. You will DESTROY the KLONDIKE.
- VOC level for Klondike Paint = Under 40 grams per liter (meets LEED), clean up with water.

COMPONENTS:

KLONDIKE

Primer 900 = 1 liter (1 LT) package size = 1 Kg. Coverage = 150 – 160 sq.ft. /L

Klondike Base = 2.5 Liter = 2.5 Kg. Coverage = 148-150 sq.ft/pail of finished wall (2 coats)

Klondike Base Sample size = 1.0 liter = 50 – 60 sq.ft/pail of finished wall (2 coats)

Mixing Proportions:

- Klondike Base (2.5L) requires 15 ml of COLORI
- Klondike sample size (1.0L) requires 6 ml of COLORI
- One Colori jar will do approx: (5) 2.5 liter pails of base

KLONDIKE LIGHT

Primer 1000 = 1 liter (1 LT) package size = 1 Kg. Coverage = 150 – 160 sq.ft. /L

Klondike LIGHT Base = 2.5 Liter = 2.5 Kg. Coverage = 148-150 sq.ft/pail of finished wall (2 coats)

Klondike LIGHT Base Sample size = 1.0 liter = 50 – 60 sq.ft/pail of finished wall (2 coats)

Mixing Proportions:

- Klondike LIGHT Base (2.5L) requires 5 ml of COLORI
- Klondike sample size (1.0L) requires 2 ml of COLORI
- One Colori jar will do approx: (15) 2.5 liter pails of base

T661
KLONDIKE™ SUMMARY APPLICATION PROCESS

June 26, 2012
Page 02 of 02

Mixing Instructions

1. Stir Primer 900 or Primer 1000 by hand. Apply Primer, w/o thinning, by brush or roller to produce a primed wall w/o runs or ridges.
2. Wait 2 - 4 hours
3. If Klondike arrives premixed with COLORI; skip steps A - E.
 - a. Shake pigment jar for 1 minute to mix the colorant inside the jar. It will separate inside the jar when stored on the shelf.
 - b. Holding the Colori jar with the nozzle pointing up, calibrate to zero
 - c. Add the correct amount of pigment to the correct size base.
 - d. Stir gently by hand insuring full dispersion – do not use a powered mixing device
 - e. Add Gold or Silver if required – again mix gently by hand

Three different application methods. Always make a mock up before beginning work to 1) confirm the color and 2) your application technique if you have not used this material before. We also have application videos available on UTUBE.

A) By Trowel

1. Load small qty onto your trowel & apply a thin 1st coat, pulling material in all directions.
2. Wait 5 – 6 hours
3. Apply 2nd coat in the same way as the first
4. Wait 1 hour
5. Flatten with trowel using no product.

B) Brush & Trowel

1. Apply small qty by brush using a random X- pattern
2. Wait 20 minutes
3. Knock flat with trowel (no product)
4. Wait 5 – 6 hours
5. Apply 2nd coat the same way as step 8
6. Wait a minimum of a full 30 minutes to 1 hour, and knock flat with dry trowel.

C) Brush Only

- Apply small qty by brush using a random X- pattern
- Wait 5 – 6 hours (no knock down step)
- Apply 2nd coat the same way
- Wait 1 hour and brush aggressively with a dry brush.